XPELAIR Model FR22/30 control switch

-simplified wiring instructions-

Note:

- 1. Reference local codes for wire gage and type for your particular installation,
- 2. Ensure power is disconnected at the electrical box prior to wiring these products,
- 3. Xpelair GX, WX and RX series for the United States are 120v-1ph-60hz,
- 4. **OPTIONAL** line voltage <u>thermostat</u>, <u>de-humidistat</u>, <u>timer</u> or similar automatic switch should be installed on the primary power <u>before</u> the FR22 switch,
- 5. FR22 is designed for one fan only per switch
- 6. Set the Fan Selector Switch (located inside fan) to Position #3 refer to fan installation instructions if unfamiliar with this switch,
- 7. Recommended color code:

N/NF = white

L3/3 = Black

E/Ground = Green

2 = Red

1 = Brown

